

Application Instructions (for UV Topcoat Protectant)

HERCULINER UV Topcoat provides strong protection against sunlight and UV rays, restores shine to weathered HERCULINER bed liners and keeps a new HERCULINER bed liner looking shiny.

Tough, Weather Resistant Formula

- * Non-toxic, environmentally safe
- * Ready to use - no mixing required
- * Won't reduce skid-resistance of HERCULINER Bed Liners

DIRECTIONS:

All surfaces must be clean, sound and dry. Make sure product is thoroughly stirred. One quart of HERCULINER UV Topcoat Protectant will cover up to 90 square feet.

HERCULINER UV Topcoat Protectant can be sprayed on or applied with a brush and roller.

If spraying with a conventional type of spray gun, HERCULINER UV Topcoat Protectant may be diluted with up to 30% water (dilute only if necessary to achieve a better spray consistency). The recommended spray pressure is 35 PSI.er.et.

If applying with a brush, pour HERCULINER UV Topcoat Protectant into a small container, then start by coating the corners, edges and seams on the back side wall of the truck bed. Then finish by coating the floor from the cab to the tailgate. To speed up the application process, you can use a foam roller to apply HERCULINER UV Topcoat Protectant after you have coated the hard to reach areas with a brush.

Application To A Weathered HERCULINER Bed Liner:

- 1) Using a stiff, bristled deck brush, scrub surface with a strong detergent such as TSP (Tri-Sodium Phosphate) or Spic and Span(r).
- 2) Rinse well.
- 3) Allow to dry completely.
- 4) Apply a thin, uniform coat of HERCULINER UV Topcoat Protectant, making sure to avoid dripping or running.
- 5) Allow to dry 12 hours before use.

Application To A New HERCULINER Bed Liner:

- 1) Apply HERCULINER UV Topcoat Protectant between 4 and 24 hours after the HERCULINER bed liner is applied. If you apply the HERCULINER UV Topcoat Protectant 24 hours or more after the HERCULINER bed liner has been applied, aggressively roughen the surface with a wire brush or sand paper for proper adhesion.
- 2) Apply a thin, uniform coat of HERCULINER UV Topcoat Protectant, making sure to avoid dripping or running.
- 3) Allow to dry 12 hours before use.

NOTE: If you applied a HERCULINER bed liner more than 30 days ago, please follow the directions for application to a "Weathered HERCULINER Bed Liner" to achieve best results.

PRECAUTIONS:

Not for internal consumption. Keep out of reach of children. If skin contact occurs, wash well with soap and water.

CAUTION: BEFORE YOU START! It is very important that this product is applied in a well ventilated area. It is strongly recommended that gloves be worn while applying any HERCULINER product.